



Set the Tru-Grind head with the shaft parallel to the shaft of the chisel.

35° bowl and spindle gouges, parting tool.
Grind head with the shaft parallel to the shaft of the chisel.
Skew chisels. Set the Tru-Grind head with the shaft 25° to the shaft of the chisel.

35°

Set the Tru-Grind head with the shaft parallel to the shaft of the chisel.

55°

Set the Tru-Grind head with the shaft parallel to the shaft of the chisel.

45°

The degrees measurement shown is the slope of the end of the gouge. The second number on each spacer is the distance from the centre of the pivot point to the face of the grindstone on the line between the pivot point and wheel centre. These are designed for a 200mm wheel. When tested on a 150mm wheel they work equally well. For perfect repeatability use the same grinder for each sharpen.

100MM

50MM

197

220

210

Use these scale bars to check that your printer has not changed the page size.

0

50MM

100MM

0