

REMOVABLE INDEXING PIN

This indexing pin is used with a thin steel index plate fitted between the chuck and lathe head. This setup can be added to, or removed from, the lathe at any stage in the turning process while the turned work remains in the chuck.

This drawing is not to scale and the whole rig must be made to fit the size of your lathe and your index wheel.

Spring loaded indexing pin. At centre height for convenience, but must not be lower than the innermost index ring.

