



## **CHRISTMAS TREE DECORATION - SANTA**

The scale shown here uses a 30mm diameter dowel, 100mm long, to start the project. Larger or smaller dowel, or wood rounded between centres, may be used. This may be held in an appropriate chuck or between centres.



Turn to shape all except the very top of Santa's hat. Sand all surfaces



Part off and hand sand the very top of the hat. Poke or drill a small hole in the top of the hat. Put the ends of a loop of string into this hole and glue them in.

